

This schematic only shows the critical components and traces for a minimum footprint layout. ENABLE, Vout-programming, and other small-signal pins need to be connected and routed according to the customer application.




Table 1

Voltage Programming Connections				
Voltage Selector			Output Voltage	
VS2	VS1	VS0	VOUT	
0	0	0	3.3V	
0	0	1	2.5V	
0	1	0	1.8V	
0	1	1	1.5V	
1	0	0	1.25V	
1	0	1	1.2V	
1	1	0	0.8V	
1	1	1	External Divider*	

0 = Connect to the GND plane.
1 = Leave open. Pulled high inside the device.
* Not shown. Refer to the datasheet.